

# 一维有线扫描枪

## 简易使用指南

VZP1.0 1#

### 系统设置



0B

恢复出厂设置



0A

显示版本号



0B142

开启声音



014200

关闭声音

### 接口设置



000602

USB (默认)



000600

Ps/2 (键盘口)



000601

RS232 (串口)



000603

VCOM (USB 模拟串口)

### 扫描模式设置



013300

默认模式



013304

自动连续扫描模式



013305

闪烁模式



013302

按键延时模式

### 语言设置



0005000

美国(默认)



0005009

法国



0005010

德国



0005002

巴西

### 后缀设置



0212@r

后缀加回车



0212@r\n

后缀加回车换行



0211@[ETX]

后缀加 ETX



0210@

取消后缀